

AM174041MTL

Three Function Shower Handset

Metlex

PROFESSIONAL BATHROOM AND
WASHROOM ACCESSORIES

Easy to Install


1. Unscrew your existing shower head from the shower hose and discard along with the old washer.
2. Clean the threads on the shower hose.
3. Position the washer supplied in the connector of your shower hose and attach it to your shower head. Do not over-tighten, finger tight only.
4. To retain the best quality finish, clean product regularly with a soft damp cloth. Do not use abrasive or chemical cleaners, as these may damage the product.

Easy to Clean

- This shower head features rub clean nozzles which are easy to unblock, helping to keep limescale build up to a minimum.
- To clean, simply rub the surface of the shower head gently in a clockwise direction with your thumb to break away any hard water deposits which could affect the shower's performance.

General Safety Advice

- For safety and convenience do not use with water above 65°C or with excessively high water pressure (max 50psi/3.5 bar).
- To avoid the risk of scalding you should always check the water temperature before entering the shower.
- Always take care when using hot water, especially with children and NEVER leave a child unattended in the bathroom.



The Water Label litre per minute flow rate is only applicable when the water saving device is fitted.

***DO NOT use the water saving device with electric showers.**

MET 046 R01